



INSTRUCTION MANUAL **HAIR DRYER**

English - Norwegian

ELLE

EN HAIR DRYER

IMPORTANT SAFETY CAUTIONS

The following safety precautions should always be followed, to reduce the risk of electric shock, personal injury, or fire. Arovo cannot be held responsible for any injury or property damage cause by failure to comply with the safety cautions and regulations. It is important to read all these instructions carefully before using the product, and to save them for future reference or new users.

EXPLANATION SYMBOLS

	Read operators manual.
	Do not use over or near washbasins, bathtubs, showers or other vessels containing water.
	Declaration of Conformity. Products marked with this symbol comply with all the applicable Community regulations of the European Economic Area.
	Protection class II device in which protection against electric shock is not based solely on the basic insulation but in which there are additional safety features such as double or enhanced insulation. It is independent of the protection measures of the fixed installation.
	The packaging can be reused or recycled. Please dispose properly of any packaging material no longer required.
	If you notice any transport damage when unpacking the product, please contact your dealer without delay.

WARNINGS

- **WARNING:** Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the risks involved. Children shall not play with the appliance. Cleaning and use maintenance shall not be done by children without supervision.
- Do not keep or use the appliance in humid areas.
- Keep out of reach of children.
- Do not use attachments not recommended by the manufacturer.
- If the appliance overheats, it will switch off automatically. Unplug the appliance and let it cool down for a few minutes. Before you switch the appliance on again, check the grills to make sure they are not blocked by fluff, hair, etc.
- Always unplug the appliance immediately after use.
- Never blok the air grills
- Do not use the appliance with wet hands or let water drop on the appliance. It may cause electric shock and injury. Do not operate the electrical appliance with wet hands or if the appliance is wet.
- Do not place in, or drop water or other liquids onto the appliance. If the appliance falls into water, unplug immediately. Do not reach into water.
- Do not operate the appliance in the presence of explosive and/or flammable fumes and/or liquids.
- Do not attempt to repair or disassemble the appliance. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons, in order to avoid any risks.

- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped into water.
- Do not use an extension cord to operate the appliance. Plug the appliance directly in the electrical outlet.
- Do not bend the electrical cord.
- Keep cord away from the heated surfaces.
- Keep heated surfaces away from contact with all skin areas. Do not let eyes or bare skin touch heated surfaces.
- Do not place the heated unit directly on any surface while it is hot or still plugged in.
- Never leave the appliance unattended when plugged in. Never use while drowsy or sleepy.
- Do not store the appliance immediately after use. Wait until it is completely cool before storing.
- For additional protection, we advise you to install a residual current device (RCD) with a rated residual operating current not exceeding 30mA in the electrical circuit supplying the bathroom. Ask your installer for advice.
- Do not use the hair dryer for purposes other than styling human hair.
- When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a risk even when the appliance is switched off.

TECHNICAL DATA

- 220-240V ~ 50/60Hz 1800-2200W
- DC motor
- Foldable handle
- Cool shot function
- Switch for 0-1-2 setting
- Overheat protection
- With concentrator
- Hanging loop
- Cable length: 1,7m

GENERAL FEATURES

Please read these instructions carefully before using this product and keep them in a safe place for future reference.

1. Switch for 0-1-2 setting
2. Cool shot function
3. Foldable handle
4. With concentrator
5. Hanging loop

IN THE BOX

The packaging should contain:

- Hair dryer
- User guide: Read these instructions before use.

USE

What to do before first use:

- Remove the packaging material and inspect the device for damage.
- Do not operate the device if it is damaged in any way. Return it to your seller immediately.
- Only connect the appliance to a mains socket with the mains voltage indicated on the rating plate.
- When disconnecting the power cord from the power outlet, pull only on the plug. Never pull on the cord.
- During the first few minutes of the first use, you may notice a little smoke and a slight smell. This is normal and will soon disappear.



INTENDED USE

Warning! Only use the device externally.

- The appliance is only intended for drying and styling human hair.
- Any improper use can be dangerous!
- Preparing the hair: Wash your hair and dry it well. Comb your hair thoroughly. Do not use hairspray or other flammable chemical hair care products.
- Plug in the appliance.
- Switch the appliance on by selection the desired setting.
- The airflow and temperature can be adjusted:
 - 1-2 setting for pre-drying medium temperature or fast drying high temperature
- After drying hair, you can use the cool button to set style with a continuous flow of cool air.
- Dry your hair by making brushing movements while holding the dryer at a small distance from your hair.
- When you are finishing styling, switch off the appliance, unplug the appliance and allow it to completely cool down before cleaning or storing.

CLEANING

Unplug the appliance and allow it to cool down. Switch off the hair dryer, unplug from the power supply. Wipe over the housing using a soft damp cloth. Remove and wash the concentrator and removable rear grill in warm soapy water. Do not use hard abrasives or cleaners. Ensure all parts are dried thoroughly with a soft dry towel.

STORAGE

Unplug the appliance, allow to cool and store in its box or in a dry place. Never store it while it is hot or still plugged in. Never wrap the cord tightly around the appliance. Never hang the unit by the cord. Store the cord loosely coiled. Do not put any stress on the cord where it enters the unit, as it could cause the cord to fray and break.

ENVIRONMENT FRIENDLY DISPOSAL



This marking indicates that this product should not be disposed of with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.

WARRANTY:

The manufacturer provides warranty in accordance with the legislation of the customer's own country of residence, with a minimum of 24 months, starting from the date on which the appliance is sold to the end user.

- The warranty only covers defects in material or workmanship.
 - The repairs under warranty may only be carried out by an authorized service center. When making a claim under the warranty, the original bill of purchase (with purchase date) must be submitted.
 - The warranty will not apply in cases of:
 1. Normal wear and tear
 2. Incorrect use, e.g., overloading of the appliance, use of non-approved accessories
 3. Use of force, damage caused by external influences
 4. Damage caused by non-observance of the user manual, e.g., connection to an unsuitable main supply or non-compliance with the installation instructions
 5. Partially or completely dismantled appliances
 6. The accessories are not covered by the terms of the warranty because they are subject to wear.
- If you need more information or support, please contact us via: www.arovo.com/contact.

In accordance with our policy of continual product improvement, we reserve the right to make technical and visual changes without notice. The current version of this instruction manual can be found under www.arovo.com/manuals

CE DECLARATION OF CONFORMITY

We, Arovo B.V., Doblijn 26, 1046 BN Amsterdam, The Netherlands declare under our own responsibility that the product:

Article number: **ERP928942420 / 92383**

Article name: **ELLE HAIR DRYER**

Barcode: **8720297457425**

a) The object of the declaration described above is in conformity with the relevant Union harmonisation legislation:

EMC, LVD, ROHS, REACH.

b) Meets the conditions laid down in the following harmonised standards:

**EN 60335-2-23:2003+A1:2008+A11:2010+A2:2015, EN 60335-1:2012+A11:2014+A13:2017+A1:2019+A14:2019
+A2:2019, EN 62233:2008, EN 55014-1:2017, EN IEC 61000-3-2:2019, EN 61000-3-3:2013+A1:2019, EN 55014-
2:2015 2011/65/EU, (RoHS) and commission delegated Directive (EU)2015/863, REACH (EC)1907/2006**

The current version of this Declaration of Conformity can be found under www.arovo.com

van Dijk

Michael van Dijk - Quality manager

August 14, 2023

Amsterdam - The Netherlands

AROVO_{bv}
Doblijn 26
1046 BN Amsterdam
The Netherlands
+31 (0) 85 273 88 86

NO HÅRTØRKER

VIKTIGE SIKKERHETSINSTRUKSJONER

Følgende sikkerhetstiltak må alltid følges for å redusere risikoen for elektrisk støt, personskade eller brann. Arovo kan ikke holdes ansvarlig for personskader eller materielle skader forårsaket av manglende overholdelse av sikkerhetsreglene og -forskriftene. Det er viktig å lese alle instruksjonene grundig før du bruker produktet og deretter oppbevare dem for fremtidig referanse eller nye brukere.

FORKLARINGER AV SYMBOLER

	Les bruksanvisningen.
	Må ikke brukes over eller i nærheten av servanter, badekar, dusjer eller andre kar som inneholder vann.
	Samsvarserklæring. Produkter merket med dette symbolet er i samsvar med alle gjeldende EU-forskrifter i Det europeiske økonomiske samarbeidsområdet. EU-samsvarserklæringen kan fås ved å skrive til produsenten.
	Beskyttelsesklasse II-apparat der beskyttelse mot elektrisk støt ikke kun er basert på den grunnleggende isolasjonen, men hvor det er ekstra sikkerhetsfunksjoner som dobbelt eller forbedret isolasjon. Den er uavhengig av beskyttelsestiltakene til den faste installasjonen.
	Emballasjen kan gjenbrukes eller resirkuleres. Kast eventuelt emballasjemateriale som ikke lenger er nødvendig.
	Hvis du oppdager transportskader når du pakker ut produktet, må du kontakte forhandleren uten forsinkelser.

ADVARSLER

- **ADVARSEL:** Ikke bruk dette apparatet i nærheten av badekar, dusjer, bassenger eller andre kar som inneholder vann.
- Dette apparatet kan brukes av barn som er 8 år og eldre, samt av personer med reduserte fysiske, sensoriske eller mentale evner eller som mangler erfaring og kunnskap, hvis er under tilsyn eller har fått instruksjoner i trygg bruk av apparatet og forstår risikoen som bruken medfører. Barn skal ikke leke med apparatet. Rengjøring og vedlikehold må ikke utføres av barn uten tilsyn.
- Ikke oppbevar eller bruk apparatet i fuktige områder.
- Oppbevares utilgjengelig for barn.
- Ikke bruk tilbehør som ikke er anbefalt av produsenten.
- Hvis apparatet overopphetes, vil det slå seg av automatisk. Koble fra apparatet og la det avkjøles i noen minutter. Før du slår på apparatet igjen, må du sjekke at luftåpningene ikke er blokkert av lo, hår e.l.
- Koble alltid apparatet fra strømmen umiddelbart etter bruk.
- Blokker aldri luftåpningene
- Bruk ikke apparatet med våte hender eller på et fuktig gulv eller la vann dryppe på apparatet. Det kan forårsake elektrisk støt og personskade. Ikke bruk det elektriske apparatet med våte hender eller hvis apparatet er vått.
- Ikke plasser apparatet i eller søl vann eller andre væsker på apparatet. Hvis apparatet faller i vann, må det kobles fra strømmen umiddelbart. Ikke grip ned i vannet.
- Ikke bruk apparatet i nærvær av eksplosive og/eller brennbare gasser og/eller væsker.
- Prøv ikke å reparere eller demontere apparatet. Hvis strømledningen er skadet, må den skiftes ut av produsenten, dennes servicetekniker eller andre kvalifiserte personer for å unngå evt. risiko.
- Bruk aldri dette apparatet hvis det har skadet ledning eller støpsel, hvis det ikke fungerer som det skal, eller hvis det har falt i vann.

- Ikke bruk en skjøteledning til å bruke apparatet. Koble apparatet direkte til stikkkontakten.
- Ikke bøy den elektriske ledningen.
- Hold ledningen unna oppvarmede flater.
- Hold oppvarmede flater unna kontakt med hudområder. Ikke la øyne eller bar hud berøre varme overflater.
- Ikke plasser den oppvarmede enheten direkte på noen overflate mens den er varm eller fortsatt er tilkoblet.
- Forlat aldri apparatet uten tilsyn når det er koblet til strømnettet. Bruk aldri apparatet når du er døsig eller sovning.
- Ikke legg bort apparatet til oppbevaring umiddelbart etter bruk. Vent til det er helt avkjølt før du oppbevarer det.
- som ekstra beskyttelse anbefaler vi at du installerer en jordfeilbryter (RCD) med en nominell driftsstrøm som ikke overstiger 30 mA i den elektriske kretsen som forsyner badet. Spør installatøren om råd.
- Ikke bruk hårføneren til andre formål enn å style menneskehår.
- Når apparatet brukes på et bad, må du koble det fra stikkkontakten etter bruk siden nærhet til vann utgjør en risiko selv når apparatet er slått av.

TEKNISKE DATA

- 110-240V~50/60Hz, 40W
- Temperaturregulering med LED-display
- Temperaturjusteringsknapper
- På/Av-knapp
- Keramisk belegg rør ø 25mm
- Spiss med kjølig berøring
- 360 graders swivelstrømledning
- Hengeløkke
- Justerbar temperaturfunksjon
- PTC varmeelement
- Topptemperatur: 220°C
- Autoutkobling
- Kabellengde: 1,9m

GENERELLE FUNKSJONER

Les denne bruksanvisningen grundig før du bruker dette produktet og oppbevar den på et sikkert sted for fremtidig referanse.

1. Bryter for innstilling 0-1-2
2. Kaldluftfunksjon
3. Sammenleggbart håndtak
4. Med konsentrator
5. Hengeløkke

I ESKEN

Emballasjen skal inneholde:

- Hårtørker
- Bruksanvisning: Les bruksanvisningen før bruk

BRUK

Gjør dette før første gangs bruk:

- Fjern emballasjen og inspisér apparatet for skade.
- Bruk aldri apparatet hvis det er skadet på noen måte. Returner det til selgeren umiddelbart.
- Koble apparatet kun til en stikkontakt med nettspenningen som er angitt på typeskiltet.
- Trekk bare i støpselet når du kobler strømledningen fra strømuttaket. Trekk aldri i ledningen.
- I løpet av de første minuttene ved første gangs bruk kan det oppstå litt røyk og lukt. Dette er normalt og vil snart forsvinne.
- Vær klar over at noen overflater kan bli varme. Ikke berør og instruer andre om dette. Enheten er MEGET VARM når den er i bruk. Sørg for å unngå kontakt mellom den varme overflaten og bar hud når den er i bruk, spesielt rundt ørene, ansiktet og halsen.



BEREGNET BRUK

Advarsel! Bruk enheten kun utvendig.

- Apparatet er kun beregnet til tørking og styling av menneskehår.
- All feil bruk kan være farlig!
- Klargjøring av håret: Vask håret og tørk det godt. Gre håret grundig. Ikke bruk hårspray eller andre brennbare kjemiske hårpleieprodukter.
- Koble til apparatet.
- Slå på apparatet ved å velge ønsket innstilling.
- Luftstrømmen og temperaturen kan justeres:
 - 1-2 innstilling for fortørking middels temperatur eller hurtigtørkende høy temperatur
- Etter å ha tørket håret kan du bruke kjøleknappen for å style håret med en kontinuerlig strøm av kjølig luft.
- Tørk håret ved å gjøre børstebevegelser mens du holder tørkeren ganske nær håret.
- Når du er ferdig med stylingen, slår du av apparatet, kobler det fra og lar det avkjøles helt før rengjøring eller oppbevaring.

RENGJØRING

Koble fra apparatet og la det avkjøles. Slå av hårføneren, koble fra strømforsyningen. Tørk av huset med en myk fuktig klut. Fjern og vask konsentratoren og den avtakbare bakgrillen i varmt såpevann. Ikke bruk harde slipemidler eller rengjøringsmidler. Sørg for at alle deler tørkes grundig med et mykt, tørt håndkle.

OPPBEVARING

Trekk ut støpselet, la apparatet avkjøles og oppbevar det i esken eller på et tørt sted. Oppbevar det aldri mens det er varmt eller fortsatt er tilkoblet. Vikle aldri ledningen tett rundt apparatet. Heng aldri enheten i ledningen. Oppbevar ledningen løst oppkveilet. Ikke belast ledningen der den kommer inn i apparatet, fordi det kan føre til at ledningen slites og går i stykker.

MILJØVENNLIG AVFALLSBEHANDLING



Dette merket angir at dette apparatet ikke må kastes sammen med husholdningsavfall i EU. For å unngå mulig miljøskade eller skade på menneskers helse som skyldes ukontrollert avfallsavhandling, må produktet resirkuleres på en måte som legger til rette for bærekraftig gjenbruk av materialressurser. Buk miljøstasjonene eller returpunktene som er tilgjengelig der du bor, eller kontakt forhandleren der apparatet ble kjøpt. Forhandleren kan ta i mot dette produktet og sørge for miljøvennlig resirkulering.

GARANTI:

Produsenten gir garanti i henhold til lovgivningen i kundens eget bostedsland, med minimum 24 måneder, fra datoen da apparatet ble solgt til sluttbrukeren.

- Garantien dekker kun feil i materialer eller arbeidsutførelse.
- Reparasjonene under garantien kan kun utføres av et autorisert servicesenter. Når du reiser et krav under garantien, må den originale kjøpskvitteringen (med kjøpsdato) sendes inn.
- Garantien gjelder ikke i tilfelle:

1. Normal slitasje
2. Feil bruk, for eksempel overbelastning av apparatet, bruk av ikke-godkjent tilbehør
3. Bruk av makt, skade forårsaket av ytre påvirkninger
4. Skader forårsaket av manglende overholdelse av bruksanvisningen, for eksempel tilkobling til en uegnet strømforsyning eller manglende overholdelse av installasjonsinstruksjonene
5. Delvis eller helt demonterte apparater
6. Tilbehør dekkes ikke av garantien fordi det er utsatt for slitasje.

Hvis du trenger mer informasjon eller støtte, kan du kontakte oss via: www.arovo.com/contact.

I samsvar med vår policy om kontinuerlig produktforbedring forbeholder vi oss retten til å foreta tekniske og visuelle endringer uten varsel.
Den gjeldende versjonen av denne bruksanvisningen finner du på www.arovo.com/manuals

EU-SAMSVARSERKLÆRING

Vi, Arovo B.V., Doblijn 26, 1046 BN Amsterdam, The Netherlands erklærer på eget ansvar at produktet:

Artikkelnummer: **ERP928942420 / 92383**

Artikkelnavn: **ELLE HAIR DRYER**

Strekkode: **8720297457425**

a) Gjenstanden for erklæringen beskrevet ovenfor er i samsvar med relevant harmoniseringslovgivning i EU:

EMC, LVD, ROHS, REACH.

b) Oppfyller vilkårene fastsatt i følgende harmoniserte standarder:

**EN 60335-2-23:2003+A1:2008+A11:2010+A2:2015, EN 60335-1:2012+A11:2014+A13:2017+A1:2019+A14:2019
+A2:2019, EN 62233:2008, EN 55014-1:2017, EN IEC 61000-3-2:2019, EN 61000-3-3:2013+A1:2019, EN 55014-
2:2015 2011/65/EU, (RoHS)and commission delegated Directive (EU)2015/863, REACH (EC)1907/2006**

Den gjeldende versjonen av denne samsvarserklæringen finner du på www.arovo.com

van DIJK

Michael van Dijk - Kvalitets ansvarlig

14 august 2023

Amsterdam - Nederland

AROVO_{bv}
Doblijn 26
1046 BN Amsterdam
The Netherlands
+31 (0) 85 273 88 86



ELLE

used by AROVO BV under license from
HACHETTE FILIPACCHI PRESSE, France.

ELLE HAIR DRYER
ERP928942420 / 92383
2023-10401
Made in China



PLEASE
RECYCLE

Imported by Europris AS
Dikeveien 57, 1661 Rolvsøy, Norway

Manufactured and designed by Arovo B.V.
Doblijn 26, 1046 BN Amsterdam
The Netherlands, www.arovo.com